

### wiScribePro A4 WIFI – Device Configuration

Step 1: Extract the app 'wiSrcibePro\_Config'

Step 2: Open the folder and run 'wiScribe WifiConfig.exe'

Step 3: The wiScribe WiFi Configuration app window will appear



Step 4: Enter WIFI Name & Password (WIFI Router/Mobile Hotspot) (Name & Password's character should not more than 10 characters)

Step 5: Switch on iScribe' s WIFI device and connect through USB cable

Step 6: Once done, please click 'Confirm''

Step 7: The successful dialog will appear.



Step 8: Press 'Ok'.

Step 9: Open iScribe app


Step 10: Verify the Device  
USB and




connect through USB and  
press




Select




Step 11: Once connect, the app will show device ID



Step 12: Then press



Step 13: Once done, the window will appear 'Device: Device ID configured Successfully'




Step 14: Then press 'Ok'. Press 'Disconnect' and unplug the device from USB.

Step 15: Verify device is in WIFI mode and select



and press 'Connect'

Step 16: The window will appear



Step 17: Then start writing and the other features are same as per the iScribe user manual